


C Series Recessed. Electric Heated Range



Item No.	Description	C1000ER -Part No.	C1500ER -Part No.	C2000ER -Part No.
1	GRILLE ASSEMBLY	5372420R	5372440R	5372460R
2	FAN DECK ASSEMBLY	5252380	5252385	5252380/5252390
3	ELEMENT ASSEMBLY	7293100	7293150	7293100/7293200
4	THERMAL CUT OUT	7851115	7851115	7851115
5	BACK CASE	6021715	6021735	6021755
6	MOTOR	7551201	7551201	7551201
7	END CAP - LH	6601820	6601820	6601820
8	END CAP - RH	6601821	6601821	6601821
9	ECOPOWER BOARD	7263701	7263701	7263701
10	ECOPOWER REMOTE CONTROL	7263630	7263630	7263630
11	MOTOR END IMPELLOR	7421240	7421251	7421240
12	DRIVEN END IMPELLOR	-	7421250	7421241